CENTRAL LOCK INSTALLATION USER'S MANUAL <u>IDC and</u> IELC.

Before starting the installation, read the entire Installation Instruction carefully!!!

Please be careful when connecting wires!!!

Remove the left rear light!




Fig. 1

3 Feed black and red cables near to battery (Fig. 2) and connect black




Fig. 2

5 Feed the cable through brake into the chine! (Fig. 5 and Fig. 6)






Fig. 3

4 Connect grey cable from hardtop to brake light red wire (Fig. 4)






Fig. 6 Fig. 6



6 Locate the plug indicated in the drawing (Fig. 7) where the car central lock cables are and connect blue and blue/red cables on vehicle loom to white and another to brown. Test and change when hardtop lock does not work correctly!



Fig. 7

Re-install the left rear light! (Fig. 8)




Fig. 8

When connecting wires it is recommended to use electrical tester to get correct fitting. When testing cables you should get a 12v flash reading when pressing the central locking. Cover any connection with electrical tape and keep away cables from heat sources such as exhaust system.

It is strongly recommended that installation is done by licenced Auto Electrician!!!

Any electrical faults due to improper installation will not be warranted by PLB Vindic AB!!!

